

Click to prove  
you're human





























(over) (Regular diagnosis)Indicator ON/Halt steering assist immediatelyReset14-01EPS ECU internal circuit (Power relay stuck ON) (Initial diagnosis)Indicator ON/Halt steering assist immediatelyReset14-02EPS ECU internal circuit (Fail-safe relay 1 stuck ON) (Initial diagnosis)Indicator ON/Halt steering assist immediatelyReset14-03EPS ECU internal circuit (Fail-safe relay 2 stuck ON) (Initial diagnosis)Indicator ON/Halt steering assist immediatelyReset14-04EPS ECU internal circuit (Power relay stuck open) (Regular diagnosis)Indicator ON/Halt steering assist immediatelyReset15-014WD selectable system blinking communication line (Regular diagnosis)4WD indicator blink (EPS indicator will not come ON)/2WD assist power stabilizedRevest15-024WD selectable system communication line voltage (Regular diagnosis)Indicator ON/2WD assist power stabilized or EPS operating is normallyRevest16-01EPS ECU internal circuit (Direction determine logic circuit) (Regular diagnosis)Indicator ON/Halt steering assist immediatelyReset16-02EPS ECU internal circuit (INH output circuit) (Initial diagnosis)Indicator ON/Halt steering assist immediatelyReset17-01EPS ECU internal circuit (Voltage raise transformation circuit) (Initial diagnosis)Indicator ON/Halt steering assist immediatelyReset17-02EPS ECU internal circuit (Voltage raise transformation circuit) (Regular diagnosis)Indicator ON/Halt steering assist under the Specified conditionRevest18-01EPS ECU internal circuit (Current sensor) (Initial diagnosis)Indicator ON/Halt steering assist immediatelyReset18-02EPS ECU internal circuit (Current sensor off set) (Regular diagnosis)Indicator ON/Halt steering assist immediatelyReset18-03EPS ECU internal circuit (Current sensor stuck low) (Initial diagnosis)Indicator ON/Halt steering assist immediatelyReset18-04EPS ECU internal circuit (Current sensor stuck low) (Regular diagnosis)Indicator ON/Halt steering assist immediatelyReset18-05EPS ECU internal circuit (Motor current deflection) (Regular diagnosis)Indicator ON/Halt steering assist immediatelyReset18-06EPS ECU internal circuit (IM2) (Regular diagnosis)Indicator ON/Halt steering assist immediatelyReset21-01Abnormal motor terminal voltage (Initial diagnosis)Indicator ON/Halt steering assist immediatelyReset21-02Abnormal motor terminal voltage (Regular diagnosis)Indicator ON/Halt steering assist immediatelyReset21-03Open in the motor harness (Regular diagnosis)Indicator ON/Halt steering assist immediatelyReset22-01Failure to initialize the torque sensor (Initial diagnosis)Indicator blink (DTC will not store in the EPS ECU)/Halt steering assist until the torque sensor is initializedLatch23-01Low/high voltage for the torque sensor (VT1 and VT6) (Regular diagnosis)Indicator ON/Halt steering assist until the DTC is erasedLatch23-02Torque sensor (VT3 Differential-amplification Function) (Regular diagnosis)Indicator ON/Halt steering assist until the DTC is erasedLatch23-03Torque sensor (VT1, VT2 rapid change) (Regular diagnosis)Indicator ON/Halt steering assist until the DTC is erasedLatch23-04Torque sensor (Temperature sensor) (Regular diagnosis)Indicator ON/Halt steering assist immediatelyReset23-05Torque sensor (Sensor Coil) (Regular diagnosis)Indicator ON/Halt steering assist until the DTC is erasedLatch24-01Engine speed signal (Regular diagnosis)Indicator ON/Halt steering assist under the Specified conditionRevest31-01Low/high IG1-terminal voltage (Initial diagnosis)Indicator ON/Halt steering assist under the Specified conditionRevest31-02Low/high IG1-terminal voltage (Regular diagnosis)Indicator ON/Halt steering assist under the Specified conditionRevest32-01Low/high VBU voltage (Regular diagnosis)Indicator ON/Halt steering assist under the Specified conditionRevest33-02EPS ECU internal circuit (EEPROM) (Regular diagnosis)Indicator ON/Halt steering assist immediatelyReset35-01EPS ECU internal circuit (CPU) (Initial diagnosis)Indicator ON/Halt steering assist immediatelyReset35-02EPS ECU internal circuit (CPU communication) (Initial diagnosis)Indicator ON/Halt steering assist immediatelyReset35-03EPS ECU internal circuit (CPU communication) (Regular diagnosis)Indicator ON/Halt steering assist under the Specified conditionRevestDTCFunction FailureSymptom/Fail-safe functionDetection timingType11-01Excessive change of vehicle speed signalIndicator ON/Substitution control of the engine RPMRegularRevest11-02Comparison between vehicle speed and engine speed signalIndicator ON/Substitution control of the engine RPMRegularRevest13-01EPS ECU internal circuit (Lower FET stuck ON)Indicator ON/Disables steering assist immediatelyInitialReset13-02EPS ECU internal circuit (Upper FET stuck ON)Indicator ON/Disables steering assist immediatelyInitialReset13-03EPS ECU internal circuit (FET stuck ON)Indicator ON/Disables steering assist immediatelyRegularReset13-04EPS ECU internal circuit (FET stuck ON (VM))Indicator ON/Disables steering assist immediatelyRegularReset13-05EPS ECU internal circuit (FET stuck ON (over current, >accumulated\*))Indicator ON/Disables steering assist immediatelyRegularReset14-01EPS ECU internal circuit (Power relay stuck ON)Indicator ON/Disables steering assist immediatelyInitialReset14-02EPS ECU internal circuit (Fail-safe relay 1 stuck ON)Indicator ON/Disables steering assist immediatelyInitialReset14-03EPS ECU internal circuit (Fail-safe relay 2 stuck ON)Indicator ON/Disables steering assist immediatelyInitialReset14-04EPS ECU internal circuit (Power relay stuck open)Indicator ON/Disables steering assist immediatelyRegularReset15-012WD/4WD select signal blinkingDifferential lock and 4WD indicators blink (EPS indicator will not come ON)/2WD assist power stabilizedRegularRevest15-022WD/4WD select signal input ineIndicator ON/2WD assist power stabilized or EPS operating normallyRegularRevest16-01EPS ECU internal circuit (Direction determine logic circuit)Indicator ON/Disables steering assist immediatelyRegularReset16-02EPS ECU internal circuit (INH output circuit)Indicator ON/Disables steering assist immediatelyInitialReset17-01EPS ECU internal circuit (Voltage raise transformation circuit)Indicator ON/Disables steering assist under the Specified conditionRegularReset18-01EPS ECU internal circuit (Current sensor)Indicator ON/Disables steering assist immediatelyInitialReset18-02EPS ECU internal circuit (Current sensor off set)Indicator On/Disables steering assist immediatelyRegularReset18-03EPS ECU internal circuit (Current sensor stuck low)Indicator On/Disables steering assist immediatelyInitialReset18-04EPS ECU internal circuit (Current sensor stuck low)Indicator On/Disables steering assist immediatelyRegularReset18-05EPS ECU internal circuit (Motor current deflection)Indicator On/Disables steering assist immediatelyRegularReset18-06EPS ECU internal circuit (IM2)Indicator On/Disables steering assist immediatelyRegularReset21-01Abnormal motor terminal voltageIndicator On/Disables steering assist immediatelyInitialReset21-02Abnormal motor terminal voltageIndicator On/Disables steering assist until the torque sensor is initializedRegularReset21-03Open in the motor harnessIndicator On/Disables steering assist immediatelyRegularReset22-01Failure to initialize the torque sensorIndicator On/Disables steering assist until the torque sensor is initializedRegularLatch23-01Low/high voltage for the torque sensor (VT1 and VT2)Indicator ON/Disables steering assist until the DTC is erasedRegularLatch23-02Torque sensor (VT3 Differential-amplification Function) (Regular diagnosis)Indicator ON/Halt steering assist until the DTC is erasedRegularLatch23-03Torque sensor (VT1, VT2 rapid change) (Regular diagnosis)Indicator ON/Halt steering assist until the DTC is erasedRegularLatch23-04Torque sensor (Temperature sensor)Indicator On/Disables steering assist immediatelyRegularReset23-05Torque sensor (Sensor Coil)Indicator ON/Disables steering assist until the DTC is erasedRegularLatch24-01Engine speed signalIndicator On/Disables steering assist under the Specified conditionRegularRevest31-01Low/high IG-1 terminal voltageIndicator On/Disables steering assist under the Specified conditionInitialRevest31-02Low/high IG-1 terminal voltageIndicator On/Disables steering assist under the Specified conditionRegularRevest32-01Low/high VBU voltageIndicator On/Disables steering assist under the Specified conditionRegularReset33-02EPS ECU internal circuit (EEPROM)Indicator On/Disables steering assist immediatelyInitialReset35-01EPS ECU internal circuit (CPU)Indicator On/Disables steering assist immediatelyInitialReset35-02EPS ECU internal circuit (CPU communication)Indicator On/Disables steering assist immediatelyInitialReset35-04EPS ECU internal circuit (CPU communication)Indicator On/Disables steering assist under the Specified conditionRegularResetDTC (" - " blinks)Function FailureSymptom/Fail-safe function8-1 (8)TP sensor circuit low voltage (less than 0.22 V) TP sensor or its circuit malfunction Poor engine acceleration Poor engine acceleration 0 ESP does not work8-2 (8)TP sensor circuit High voltage (more than 4.93 V) Loose or poor contact of the TP sensor connector TP sensor or its circuit malfunction Poor engine acceleration Fail-safe value: 0 ESP does not work8-3 (8)TP sensor circuit Low voltage (more than 4.93 V) Loose or poor contact of the TP sensor connector MAP sensor or its circuit malfunction Engine operates normally Pre-program value: 64 kPa7-1ECT sensor circuit low voltage (less than 0.15 V) ECT sensor or its circuit malfunction Hard to start at low temperature Pre-program value: 78.6°C/173.5°F Cooling fan turns on7-2ECT sensor circuit high voltage (more than 4.981 V) Loose or poor contact of the ECT sensor connector ECT sensor or its circuit malfunction Hard to start at low temperature Pre-program value: 78.6°C/173.5°F Cooling fan turns on8-1TP sensor circuit low voltage (less than 0.107 V) Loose or poor contact of the TP sensor connector TP sensor or its circuit malfunction Poor engine acceleration Fail-safe value: 0 ESP does not work8-2 (2)Shift angle sensor response (Control motor lock) PCM activates the motor but the angle sensor voltage does not change in middle position Control motor or its circuit malfunction Shift angle sensor or its circuit malfunction ESP does not work22-2 (2)Shift angle sensor response (Control motor stuck) PCM does not activate the motor but angle sensorvoltage stays out of middle position (195 - 3.05 V) Control motor or its circuit malfunction Shift angle sensor or its circuit malfunction ESP does not work23-1 (23)Shift angle sensor response (Voltage variation) PCM does not activate the motor but angle sensor voltage varies constantly Shift angle sensor installation problem Shift angle sensor or its circuit malfunction Control motor or its circuit malfunction ESP does not work24-1 (24)Shift control motor drive circuit Control motor or its circuit malfunction Control motor drive circuit malfunction ESP does not work32-1 (32)Fail-safe relay circuit Fail-safe relay circuit malfunction ESP does not work33-2 (33)EEPROM malfunction Engine operates normally41-1 (41)Gear position switch circuit Gear position switch circuit malfunction (Short) Engine does not start ESP does not work Gear position indicator blinks "-41-2 (41)Gear position switch circuit Gear position switch circuit malfunction (Open) ESP does not work Gear position indicator blinks "-42-1 (42)Gearshift (UP/DOWN) switch circuit Gearshift (UP/DOWN) switch circuit malfunction (Short) ESP does not workDTCFunction FailureSymptom/Fail-safe function1-1MAP sensor circuit low voltage (less than 0.195 V) MAP sensor or its circuit malfunction Engine operates normally Pre-program value: 64 kPa1-2MAP sensor circuit high voltage (more than 3.804 V) Loose or poor contact of the MAP sensor connector MAP sensor or its circuit malfunction Engine operates normally Pre-program value: 64 kPa7-1ECT sensor circuit low voltage (less than 0.015 V) ECT sensor or its circuit malfunction Hard to start at low temperature Pre-program value: 78.6°C/173.5°F Cooling fan turns on7-2ECT sensor circuit high voltage (more than 4.981 V) Loose or poor contact of the ECT sensor connector ECT sensor or its circuit malfunction Hard to start at low temperature Pre-program value: 78.6°C/173.5°F Cooling fan turns on8-1TP sensor circuit low voltage (less than 0.107 V) Loose or poor contact of the TP sensor connector TP sensor or its circuit malfunction Poor engine acceleration Fail-safe value: 0 ESP does not work8-2 (2)Shift angle sensor response (Control motor lock) PCM activates the motor but the angle sensor voltage does not change in middle position Control motor or its circuit malfunction Shift angle sensor or its circuit malfunction ESP does not work22-2 (2)Shift angle sensor response (Control motor stuck) PCM does not activate the motor but angle sensorvoltage stays out of middle position (195 - 3.05 V) Control motor or its circuit malfunction Shift angle sensor or its circuit malfunction ESP does not work23-1 (23)Shift angle sensor response (Voltage variation) PCM does not activate the motor but angle sensor voltage varies constantly Shift angle sensor installation problem Shift angle sensor or its circuit malfunction Control motor or its circuit malfunction Control motor drive circuit malfunction ESP does not work32-1 (32)Fail-safe relay circuit Fail-safe relay circuit malfunction ESP does not work33-2 (33)EEPROM malfunction Engine operates normally41-1 (41)Gear position switch circuit Gear position switch circuit malfunction (Short) Engine does not start ESP does not work Gear position indicator blinks "-41-2 (41)Gear position switch circuit Gear position switch circuit malfunction (Open) ESP does not work Gear position indicator blinks "-54-1Bank angle sensor circuit low voltage Bank angle sensor or its circuit malfunction Engine operates normally Bank angle sensor stops the control54-2Bank angle sensor circuit high voltage Loose or poor contact of the bank angle sensor connector Bank angle sensor or its circuit malfunction Engine operates normally Bank angle sensor stops the control6-1(FAmodelonly)Rear VS sensor no signal Loose or poor contact of the rear VS sensor connector Rear VS sensor or its circuit malfunction Gearshift function does not work (2nd, 4th or reverse gear only)67-1(FAmodelonly)Front VS sensor no signal Loose or poor contact of the front VS sensor connector Front VS sensor or its circuit malfunction Engine operates normally Gearshift function does not work (2nd, 4th or reverse gear only)DTCFunction FailureSymptom/Fail-safe function9-1Differential lock motor continuous operation (more than 3.2 seconds) in positive rotation Differential lock system parts or its circuit malfunction Faulty PCM/ECM Differential lock/4WD indicators blink/Disables differential lock system9-1Differential lock motor continuous operation (more than 3.2 seconds) in negative rotation Differential lock system parts or its circuit malfunction Faulty PCM/ECM Differential lock/4WD indicators blink/Disables differential lock system92-1Differential lock motor both terminals high voltage (more than 2.99 V) Differential lock system parts or its circuit malfunction Faulty PCM/ECM Differential lock/4WD indicators blink/Disables differential lock system94-1Unusual voltage input pattern on differential lock motor terminal Differential lock system parts or its circuit malfunction Differential lock/4WD indicators blink/Disables differential lock system95-1Differential lock motor operation in negative rotation without operating the pull back relay in changing to differential lock Differential lock system91-1Differential lock motor terminal MIL blinks4-1 (4)Dual clutch PC solenoid valve Low input Loose or poor contact of the dual clutch PC solenoid valve connector Dual clutch PC solenoid valve or itscircuit malfunction Gearshift function does network (2nd, 4th or reversegear only)-4-2 (4)Dual clutch PC solenoid valve High input Dual clutch PC solenoid valve or its circuit malfunction Gearshift function does network (2nd, 4th or reversegear only)-4-3 (4)Dual clutch PC solenoid valve drive circuit Dual clutch PC solenoid valve or its circuit malfunction Gearshift function does network (2nd, 4th or reversegear only)-9-1 (8)TP sensor circuit Low voltage TP sensor or its circuit malfunction TP sensor or its circuit malfunction Poor engine acceleration Fail-safe value: 0 Gearshift function does network (2nd, 4th or reversegear only)88-2 (8)TP sensor circuit High voltage Front VS sensor or its circuit malfunction Poor engine acceleration Fail-safe value: 0 Gearshift function does network (2nd, 4th or reversegear only)815-1 (15)Shift solenoid valve circuit Loose or poor contact of the shift solenoid valve connector Shift solenoid valve or its circuit malfunction Gearshift function does network (2nd, 4th or reversegear only)-21-1 (21)Shift spindle angle sensor circuit Low voltage Loose or poor contact of the shift spindle angle sensor connector Shift spindle angle sensor or its circuit malfunction Gearshift function does network (2nd, 4th or reversegear only)-21-2 (21)Shift spindle angle sensor circuit High voltage Shift spindle angle sensor or its circuit malfunction Gearshift function does network (2nd, 4th or reversegear only)-22-1 (22)Shift spindle operation malfunction (while operating gearshift mechanism) Control motor or its circuit malfunction Shift spindle angle sensor or its circuit malfunction Gearshift function does network (2nd, 4th or reversegear only)-23-1 (23)Shift spindle operation malfunction (after operating gearshift mechanism) Shift spindle angle sensor installation problem Shift spindle angle sensor or its circuit malfunction Gearshift function does network (2nd, 4th or reversegear only)-24-1 (24)Shift control motor drive circuit Loose or poor contact of the shift control motor connector Control motor or its circuit malfunction Control motor drive circuit malfunction Gearshift function does network (2nd, 4th or reversegear only)-32-1 (32)Fail-safe relay circuit Fail-safe relay circuit malfunction Gearshift function does network (2nd, 4th or reversegear only)-41-1 (41)Shift drum position switch circuit Shift drum position switch or its circuit malfunction (Short) Gearshift function does network (2nd, 4th or reversegear only)4142-1 (42)Gearshift switch circuit Gearshift switch or its circuit malfunction Gearshift function does network (2nd, 4th or reversegear only)-44-1 (44)EOT sensor circuit low voltage (less than 0.08 V) EOT sensor or its circuit malfunction Gearshift function does network (2nd, 4th or reversegear only) Cooling fan turns on444-2 (44)EOT sensor circuit high voltage (more than 4.92 V) Loose or poor contact of the EOT sensor connector EOT sensor or its circuit malfunction Gearshift function does network (2nd, 4th or reversegear only)466-1 (66)Rear VS sensor no signal Loose or poor contact of the rear VS sensor connector Rear VS sensor or its circuit malfunction Gearshift function does network (2nd, 4th or reversegear only)6667-1 (67)Front VS sensor no signal Loose or poor contact of the front VS sensor connector Front VS sensor or its circuit malfunction Gearshift function does network (2nd, 4th or reversegear only)6781-1 (81)Sub-transmission switches malfunction (Low and drive switches remain ON simultaneously for more than 1.5 seconds) Sub-transmission switch or its circuit malfunction Gearshift function does network (2nd, 4th or reversegear only)- Honda 2002 and up ES and all Rubicon models use codes to identify shift and transmission problems. The codes are different for each type/model so make sure you are following the correct procedure; ES models are listed first, followed by the Rubicon First thing to check is the volage from the battery. It should be a minimum of 12.4 volts. Check all main and accessory fuses. 2002 and newer ES Models If the gear indicator isnt flashing , you can manually interrogate for codes. 1 Turn ignition to off 2 Place tranny in neutral 3 Put on parking brake so the quad does not move. 4 Press both shift buttons (up and down), and hold them in, while turning the key to on. Make sure the N appears for gear position. Release the buttons. 5 Wait 5 secs, and then press both the switches again, and hold them in for at least 3 seconds, then release the switches. 5 The problem code is displayed by a certain number of blinks " - - " on the gear indicator, which indicates the problem code by the number of blinks. If " N " (neutral) stays ON on the position indicator, the retrieval process was not correctly performed. Repeat the procedures from step one at this time.) 6 When the problem code(s) displays, release the shift switches. You should see " - - " for approximately 3 seconds then off, then the " - - " should flash, once for code one, twice for code two and so on. The engine control module (ECM) can store two different codes. If your ECM has stored two different codes, the first code displayed is the most recent and the second code is the earlier code. Write them all down. 7 To delete an old code. Press the switches when the code is flashed No flashing, no problem. The codes point to a system with in the ES. It doesnt necessarily mean the component is bad, but that theres a fault in that circuitry. Could be a disconnected wire, shorted wire, or high resistance in the wiring, or it could be the release. The service manual gives a process of trouble shooting, to nail down where the problem is if it is a wiring/connection problem. 1 flash, ece (writing and recording circuit) , probable faulty part ECU 2 flashes ES shift switch system (up and down) probable faulty part, shift switch, related wiring harness, or ECU 3 flashes, angle sensor system, probable faulty part, angle sensor, or incorrectly installed, related wiring, or ECU 4 flashes, gear position switch system, probable faulty part, gear position switch, or related wiring, or ECU 5 flashes, angle sensor system, probable faulty part, angle sensor(short or open), or related wiring , or ECU 10 flashes, ignition pulse generator system, probable faulty part, ignition pulse generator or related wiring 11 flashes, speed sensor system(vehicle speed), probable faulty part speed sensor or related wiring or ECU 12 flashes, gear position switch system, probable faulty part gear position switch or related wiring, or ECU Rubicon Models 1. Put the gear shift lever in neutral (be sure the neutral indicator comes on) and the ignition switch OFF (vehicle at a stop). 2. While pushing the UP and DOWN shift switches (ESP) simultaneously, turn the ignition key to the on position. 3. Release the UP and DOWN switches immediately, then at the same time push both the UP and DOWN shift switches again and hold for more than 2 seconds. 4. The problem code is displayed by a certain number of blinks " - - " on the gear indicator, which indicates the problem code by the number of blinks. If " N " (neutral) stays ON on the position indicator, the retrieval process was not correctly performed. Repeat the procedures from step one at this time.) 5. When the problem code(s) displays, release the shift switches. You should see " - - " for approximately 3 seconds then off, then the " - - " should flash, once for code one, twice for code two and so on. The engine control module (ECM) can store two different codes. If your ECM has stored two different codes, the first code displayed is the most recent and the second code is the earlier code. Write them all down. To Erase the Problem Codes 1. Push and hold the UP and DOWN shift switches simultaneously for 3 seconds or more while the problem code is being displayed (i.e. " - - " blinking on the gear position indicator). 2. When the erasure is completed, the blinking pattern changes to the erasure confirmation blink. 3. Turn the ignition off. Initial Setting Procedure Note : After replacement of any of the following parts, perform the initial setting procedure below. - ECM - Throttle sensor\* - Angle sensor \*Also, perform the initial setting procedure if the throttle cable is disconnected (i.e., carburetor removal/installation, cable replacement etc.). \* The gear position blinks in Indicator Mode 2 when the initial setting was not made properly. Repeat the procedure from step 2. 1. Start the engine and let it idle about one minute with the sub-transmission in neutral. Stop the engine. 2. Make sure the gearshift lever is in the neutral position (be sure the neutral indicator comes on) and turn the ignition switch off. 3. Turn the ignition switch ON while pushing the UP and DOWN shift switches (ESP shift switches) simultaneously. 4. Release both the UP and DOWN shift switches immediately, then push and release the shift switches in the order of UP, DOWN, and UP. Do not hold the switches in. 5. A constant " - - " indication stays ON on the gear selector indicator. (If the gear position indicator shows a continuous "N", repeat the procedure from step 2.) 6. Move the throttle lever to the fully closed position, then to the fully open position, and then move it to the fully closed position again immediately (within 10 seconds) after " - - " comes ON on the gear position indicator. 7. Check the control motor operation sound (the control motor should function at this time to adjust the angle sensor). 8. When the initial setting procedure is complete, the indication on the gear selector indicator changes from the continuous lighting of " - - " to the continuous lighting of " N ". Code 1 - Ignition Pulse Generator System Code 2 - Speed Sensor System Code 3 - Gear Position Switch System Code 4 - Throttle Sensor System Code 5 - Angle Sensor System (Motor lock i.e., angle sensor, wiring, ECM, control motor, motor transmission section, transmission unit) Code 6 - Angle Sensor System (swash plate angle sensor / wiring) Code 7 - ESP shift switch system Code 8 - ECM EEPROM Code 9 - ECM voltage converter circuit Code 10 - ECM fail-safe relay circuit Code 11 - ECM motor drive circuit Code 12 - ECM CPU

- https://eobliecky.sk/userfiles/file/1f8bd1ea0-ef20-40a5-844f-8d8f28f7b992.pdf
- http://nahakhoanhan.tin.com/mehoa/ftp/file/5fca605312-42f0-9448-c04d8c-4e0556.pdf
- https://badirtech.com/app/webroot/upload/files/4ff0e912-2693-4fc3-b11e-e1f83a0062fb.pdf
- https://china-hualing.com/img/files/4210032.pdf
- http://studiotipaldo.com/userfiles/files/5ddea512\_22dc\_45e6\_ab14\_4f7e83208430.pdf
- what is virology medical term
- fazuenafo
- pakivi
- how much oil does a 2016 kx250f take
- tv series prodigal son cast